
13
USB CONNECTOR
12
USB-IDE BRIDGE
14
22
21
23
CONTROL DATA
STATUS AND PLAY DATA
VIDEO
AUDIO
11
HDD
CONNECTOR
CONNECTOR
MEDIA DECODER
10
REMOVABLE HDD CASSETTE
20
MEDIA PLAYER DOCK

FIG. 1